

This Package Contains




A x 1
(31781)



B x 2
(16029)



C x 1
(31790)



*located inside **CUSHION (C)**
D x 1
(31806)

DO NOT RETURN THIS UNIT Please make sure you have all parts prior to assembly. All SportPet® products include a 6-month limited manufacturer's warranty for defective or missing parts. If any parts are missing or damaged, please email our friendly customer service center at info@sportpet.com


Step 1

Find **PIPES (B)** located inside **CARRIER (A)** and remove them from the elastic band.



Step 2

Slide **PIPES (B)** through **SLEEVES** inside mesh side of **CARRIER (A)** as shown in **FIGURE 1**.




Cushion Cover (C) Washing Instructions:

Remove **BOARD (D)** from **CUSHION COVER (C)**.

CUSHION COVER (C) is machine washable and dryer safe.

Machine Wash on **COLD/COLD** using **GENTLE** cycle. Machine Dry on **LOW** heat or **AIR DRY**



Because every cat is different, it is important to monitor your cat's behavior with this product. If at any time your cat damages this item, or any portion of this item becomes damaged, remove the damaged portion and discontinue use of the product.